

## Warranty Information

AirScape Fans Inc. (Distributor) warrants from the date of purchase that the product supplied by Distributor is free of defects in material and workmanship for a period of 1 year. This includes the receiver and transmitter.

If a failure of the product occurs, contact Distributor at 866.448.4187 and give the model number of the product, the purchase date, proof of purchase, and a description of the problem. Customer is responsible for all inbound and outbound shipping charges related to warranty service. Once a problem is diagnosed, and proof of purchase is verified, the Distributor will have the option of shipping the necessary repair part(s) to the Customer or having the product returned to the Distributor for repair or replacement.

If the Distributor finds the returned product to be in operating condition, the product will be returned to the customer at customer's expense. Distributor reserves the right to obtain a credit card authorization for possible freight charges or non-return of defective parts/unit.

Specific warranty exclusions:

Except as provided by this express warranty, the goods are sold without any implied warranties. This limited warranty does not cover labour or field diagnosis, nor does it cover failure of the installer to follow installation instructions, damage resulting from accident, misuse or abuse, lack of maintenance, improper installation. In no event, shall the Distributor be liable for any special, incidental, or consequential damages resulting from any defect in material or workmanship. It is expressly understood that Buyer's sole and exclusive remedy shall be repair or replacement of defective parts.

## Contact Information

For technical/warranty related issues or for more information on AirScape products, please contact us.

Thank you for choosing AirScape.



**Phone:** 1.866.448.4187 (8am-5pm Mon-Fri *pst*)

**Email:** [experts@airscapefans.com](mailto:experts@airscapefans.com)

**Web:** [airscapefans.com](http://airscapefans.com)



## Whole House Fan Wireless Remote Kit Operation Guide

MODEL#: AS-RMT-FM



## What's Included

- Remote Control AS-TRANS-FM
- Receiver (factory installed)

CONGRATULATIONS on your purchase of the Airscape Wireless Remote Kit.

Please take a few minutes to read over the following sections to make sure you are prepared for the installation and operation of your kit.

If you (or your installer) have any questions regarding the installation, operation, or maintenance of this product, please contact technical support.



*Local codes and standards must be followed in the installation of the wireless remote kit. Make sure your whole house fan is unplugged before performing the following steps.*


## Installation Instructions

The following steps have already been performed for you if you ordered a wireless remote kit with your AirScape unit. Skip to the “Operating Tips” section.

**STEP 1)** Remove the circuit board cover plate on your whole house fan and route the wiring of your remote control receiving unit through one of the electrical knock-outs on the circuit board.

**STEP 2)** Connect the wires from your remote control receiving unit to the appropriate locations on your whole house fan circuit board as shown in the diagram. (see **Figure 1**) **\*\*Make sure to replace the circuit board cover plate when finished.**

Figure 1




## Remote Programming/Operation

To operate your whole house fan you will need to program both buttons 1 and 2. Follow these steps to program your remote. (see **FIGURE 2** for reference)


**STEP 1)** Press “MODE” switch #1 for three seconds on the remote control receiving unit. The green LED will blink rapidly. While the LED is blinking, press button 1 on your remote control. The LED will flash now flash once, confirming that programming is successful.

Figure 2



**STEP 2)** Press the “MODE” switch #2 for three seconds on the remote control receiving unit. The red LED will blink rapidly. While the LED is blinking, press button 2 on your remote control. The LED will now flash once, confirming that programming is successful. You are now finished.

### Remote Button Operation



## Operating Tips & Information

### Remote Control Tips

- Up to 15 remote controls can be programmed to one whole house fan.
- Remote controls only need to be programmed once, all RF functions are stored to memory.
- The remote uses two CR2016 3v batteries. To replace them, simply remove the screws and back cover.
- The remote has an indoor range of about 60 ft.

### General Whole House Fan Tips

- Only use it when the outdoor air is cooler than your indoor air.
- Make sure your A/C is off when you run the fan or you'll be blowing expensive A/C air right out of your house. We recommend running your whole house fan all night long. Here's why: The goal is to cool your entire house down, not just the air. It takes time to pull the heat out of the sheetrock, structure and contents of a house. By ventilating all through the night, the house starts the next day thoroughly cooled so you can delay or eliminate running energy consuming air conditioning the next day.
- Use high-speed to quickly cool down the house and low setting to run quietly through the night.
- Your whole house fan is only effective with open windows.

*Feel free to contact us if you have any further questions.*